

## Silver-Lux Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974  
Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

**Please read all instructions before installation and to check to see that all parts are included.**

KIT CONTENTS:	
Description	Qty
Silver-Lux Bulbs	2
Driver Harness	2
Anti-Flicker Harness (Not included in H16 Kit)	2
Hex Wrench (Not included in H16 Kit)	1

### Silver-Lux Installation

1. Install driver and anti-flicker harnesses onto the bulbs. Fan out copper braids. Refer to Figure 1.



*(Representative image only. Actual bulb may differ.)*

2. Replace existing bulbs with the Silver-Lux LED bulbs.
  - a) If your vehicle is equipped with cover to seal the bulb, you may need to tuck the anti-flicker and driver harnesses into the headlight assembly before you install the Silver-Lux bulb. Tuck the braids into the headlight housing as shown in Figure 2 and replace cover to seal the headlight.



- b) If your headlights leave the back of the bulb out in the open, cable tie the driver and anti-flicker harnesses into a safe location so they are not able to interfere with any moving parts in the engine compartment.

### Silver-Lux Adjustment (Clocking)

***\*\*Bulbs come clocked for typical applications\*\****

1. To clock the bulbs and find the optimal light output, start by leaving the factory bulb in one headlight and replace the opposite bulb with the Silver-Lux. Face the vehicle towards a wall, 15' – 25' away, with the headlights on.
  - a) For bulbs that use a set screw to lock the collar in place, use the provided Hex wrench to loosen the set screw. Refer to Figure 3. Rotate the bulb in the housing until the Silver-Lux beam pattern best matches the factory halogen beam pattern. (You will want to view both low and high beams to ensure optimal orientation.) Tighten set screw to lock bulb in desired position. Remove the opposite halogen bulb and replace it with the other Silver-Lux bulb. Repeat the process to match the beam pattern of the first bulb.



- b) For bulbs that have an easy clock retaining ball. Simply insert the bulb into the headlight and rotate to desired position.