

# **T-REX**

## **Billet Grilles**

25729

**2008 HONDA**  
**ACCORD**  
**BUMPER INSERT**

25729

**2008 HONDA**  
**ACCORD**  
**BUMPER INSERT**

**2008 HONDA ACCORD**  
**BUMPER INSERT**

**Tools Required:**  
Phillip Screw Driver

**Hardware / Parts Included:**

- 1 Billet Insert
- 2 1 1/4" #6 Screws
- 2 U Nuts
- 2 2" "J" Hooks

**Read and understand instructions before attempting installation**

### **Step 1**

Center the grille insert into place. Place a machine screw in each mount on the billet insert. Install a U nut on each "J" hook. From the back side; place the screw into the u nut making sure that the J hook wraps around the factory plastic.



### **Step 2**

Tighten the screws down with the "J" hooks catching the rear edge of the bumper cover. Do not over tighten.

*Thank you for purchasing a T-Rex Billet Grille. 1/04/08*