

# **T-REX**

## **Billet Grilles**

**55801**

**06-08 INFINITI  
FX SERIES**

**55801**

**06-08 INFINITI  
FX SERIES**

### **2006-08 INFINITI FX** **UPPER CLASS SERIES MESH BUMPER**

*(Will not work with speed sensing cruise control)*

#### **Tools Required:**

5/16" Socket or Nut Driver  
10 mm Socket or Nut Driver  
Phillips & Slotted Screwdrivers

#### **Part List:**

1 Upper Class Series Bumper  
3 1/2" x 1/2" L Brackets  
3 6-32 Nylon Lock Nuts  
3 #10 Flat Washers

### **Read and understand instructions before attempting installation**

#### **Step 1**

The factory grille must be removed to install bumper grille; use a small screwdriver to remove the center from the four fasteners along the top. There is one fastener securing the bumper next to the grille; use a slotted screwdriver to pop the center and remove. The fasteners will be re-used; do not discard. Next, lightly pull the top of the grille assembly forward. Use your fingers to depress the remaining clips behind the grille. The grille can now be removed.

#### **Step 2**

Remove the chrome molding in the bumper opening. Three 10mm nuts retain the strip from behind the bumper; remove these nuts. The chrome molding is also retained with four pressure clips that snap into the bumper. Use a slotted screwdriver to pry the molding forward to release these clips if needed.



#### **Step 3**

Center the grille in place. Install an 'L' shaped bracket, washer and nut on each mounting stud. Wrap the end of each bracket around the plastic in the bumper opening. Tighten the hardware until the grille is held securely in place. If needed, loosen the hardware and adjust. Re-install the upper grille onto the vehicle.

***Thank you for purchasing a T-Rex Billet Grille. 11/30/06***