



**The Only Bedliner That Works™**

## 2015 Ford F-150 5.5' Installation Instructions

**\*Requires Torx T30 bit and Torx T25 bit,  
NOT INCLUDED**

While temperature does not affect your DualLiner, it is easier to install when the bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a “set” while rolled. If possible, unroll the mat and let it “relax” in the sun to make it easier to work with. If installing in cold weather it may take several weeks for the mat to fully relax.

First, using a **T30 Bit** remove all eight tie downs on the sidewalls (24 screws in total).

Snap the loadguard, or front panel, over the rail at the cab end of the bed. Install the sidewalls and starting by the cab, tuck the top edge under the rail cap. The sidewall panel will tuck under in the front, around the two pillars above the wheel well and at the rear near the tailgate. Next, start reinstalling all tie-downs over the panel. Note, you may have to lift the panel slightly to reinstall and align some of the holes.



If your truck is equipped with LED lights, there are pre-cut holes for both lights and the switch. If your truck is equipped with a bed extender, you will see three pin marks at the back edge of the side panel that aligns with the holes for your bed extender. Open these up to the correct size with a drill bit and reinstall your bed extender.



Once all the tie-downs are reattached it's time to insert the mat. With ribbed side up and with the mat part number visible on the lower right side of the truck bed, lift the mat into the truck bed. Begin tucking the mat into the channel at the front (by the cab) of the truck on one side of the bed and repeat for the opposite side. Make sure the mat is pulled tightly to the front of the truck.





**The Only Bedliner That Works™**

## 2015 Ford F-150 5.5' Installation Instructions PAGE 2 of 2

The next step is installing the tailgate panel. Using a **T25 Bit**, remove all eight screws across the top half of the tailgate. Place the black square tape over the four outside holes. Align tailgate panel and using shoulder bolts loose fit the four center holes.



On the four outside bolts, place supplied metal washers on shoulder bolt and loosely attach panel. Return to the center bolts and retighten from center to outside bolts.



We've also provided double sided tape which can be used to help hold any of the panels.



**The Only Bedliner That Works™**

143 S. Main St, 2<sup>nd</sup> Floor  
West Bend, WI 53095  
800-992-1949  
262-626-1034  
262-626-2735 Fax

### **Real Lifetime Warranty**

Thank you for selecting the DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the DualLiner bedliner against defects in material and workmanship for the life of the bedliner. Warranty is transferable to new owner of truck or bedliner. Failures due to improper installation are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability: The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are effected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to [www.DualLiner.com](http://www.DualLiner.com) for warranty registration.

---

#### **FORD F SERIES 2015 INSTALLATION PARTS:**

(FOF15PAK)

4 Square Tape Pieces (Black)

8 Shoulder Bolts

4 Washers

Optional Items for added hold:

1 Alcohol Wipe

4 Strips Double Sided Tape (White)