



IMPORTANT!

READ BEFORE OPENING

Unpacking Instructions

- 1) Remove the clear shrink-wrap protective layer. You may cut it if necessary but be sure not to cut the box. This layer can be discarded.
- 2) Notice the brake or overlay of the cardboard toward the center of the box. This is a two piece box with a top and a bottom.
- 3) (Use 3 people for this step) Stand the box on its end and slide the top cover off.
- 4) Lay the box back flat on the ground carefully. Have one individual on each corner of the front of the exposed lid/foam and the other individual slide the bottom layer of the box off of the cover.
- 5) Carefully (being mindful of the painted surface of the cover) lay the cover back on the floor on the shipping wood on the underside of the cover.
- 6) Remove foam and plastic covering being mindful that you will need to replace it in the case of a warranty or return. If you must cut the clear plastic shrink-wrap, be VERY careful of the painted surface of the tonneau cover. Cuts and chips in the paint will not be covered under warranty.
- 7) The Tonneau Cover is still covered in a white plastic wrap. **DO NOT ATTEMPT TO CUT THIS OFF.** There are screws holding it in place in the bottom of the shipping boards. Remove the bolts and the white plastic wrap will release. Take the plastic wrap off.
- 8) Now that the tonneau cover is exposed you will need to remove the shipping wood from the underside of the cover. **DO NOT FLIP THE TONNEAU COVER OVER AND SET IT ON THE PAINTED SURFACE.** Find a secure stand to set the center of the underside of the tonneau cover on that still leaves the screws exposed for the shipping boards. You could also use the two other individuals to hold the cover up while you remove these boards and begin the installation process.