



Installation Instructions: Chrome Accessories

Installing your S.E.S. chrome accessories is as easy as 1, 2, 3. Start by prepping the soon-to-be chromed surface with rubbing alcohol. Once clean, test-fit the chrome piece to the proper area. When you are confident the piece fits correctly, remove adhesive backing and install by pressing firmly in place with consistent pressure. Adhesive works best if ambient temperature is no less than 60-degrees F. After installation, polish your chrome accessories with a soft towel for an impressive shine.