

WeatherTech®

Thank you for purchasing your WeatherTech® TechLiner™. The TechLiner™ will offer incredible, affordable protection and years of reliable use if you follow these simple instructions.



Installation Instructions -

Remove all other bed and tailgate accessories prior to installation. Clean your truck bed with soap and water and dry thoroughly before installing the TechLiner™.

Remove TechLiner™ from shipping box and place on a dry, flat surface*. Unroll and lay out to allow liner to flatten. (For faster results, lay liner in the sun and put a small weight on each of the corners.)

*Take note of the location of the Velcro pads on the bottom of the TechLiner™, and prevent pads from becoming dirty or collecting debris. Do not remove the adhesive backing at this time.

After TechLiner™ has flattened, place into the bed of the truck. Align all of the features of the custom fit TechLiner™ to the features of your truck bed for a seamless fit.

Bend the TechLiner™ backward to locate the first Velcro disc without shifting the position of the TechLiner™. Remove the plastic backing from the Velcro disc and fold the TechLiner™ back into place. Press down firmly on the location of the Velcro disc.

Continue this process for each Velcro disc as you work clockwise around the truck bed. Take care to not pull apart or peel off the Velcro discs until you affix them to the truck bed.

NOTE: It is imperative to adhere the TechLiner™ to the bed of the truck as described above. Failure to do so may allow the TechLiner™ to lift during travel as a result of turbulent airflow, which could result in unsafe conditions for the operator of the vehicle or other vehicles nearby.

Clean your TechLiner™ using mild soap and water, or for best results use our TechCare™ FloorLiner™ & FloorMat Cleaner and Protector.

If you have any questions regarding the use of the product, please contact us at 800-441-6287 or www.WeatherTech.com



*Proudly Designed,
Engineered and
Manufactured
in the USA*



RECYCLABLE

MacNeil
AUTOMOTIVE
PRODUCTS LIMITED

Specialists in Original Equipment and
Aftermarket Automotive Accessories

1 MacNeil Court • Bolingbrook, IL 60440
800-441-6287 • 630-769-1500 • fax 630-769-0300

WeatherTech®.com